
Quick Start Guide

WYBOT

WYBOT C1（OS7010C）


Step 1 -Charging

1




- Unscrew protective cap, and ensure charging port dry。

3



- Fully charge your device before first use.


2



- Insert charger cable into the charging port, and keep your device at least 3m away from pool.


Step 2 -Starting the device

4



- Screw protective cap back.

5



- Press on/off button, and the LED turns solid blue.
- Put the device into the pool within 3 min., otherwise, it will power off.
- The default cleaning mode is wall then floor.


Step 3 -WYBOT App setting

6



- Please download WYBOT and set your cleaning mode in advance.
- Register your account as per App direction.
- Bind your device as per App direction.

7



- Enable your mobile phone Bluetooth.
- Keep your device out of water and within the range of Bluetooth.
- Your device will turn solid purple after a successful connection.

8




- Customize your cleaning mode via App.

Email：support@wybotpool.com Facebook: @WybotPool Website: www.wybotpool.com


Step 4 -Submerging the device

9



- Submerge the device into the pool gently.


10



- Wait for the device auto-calibration for 10 seconds.
- LED turns flashing blue and start to clean.


Step 5 -Removal from the pool

11




- Auto park by the wall when completing cleaning.

12



- Insert the included hook into a standard pool pole.


13



- Hook it out of the pool.


Step 6 -Cleaning the filter

14



- You should clean the filter after use. Insufficient cleaning may influence pool cleaning effect.

15



- Store the cleaner in a ventilated place and keep it out of direct sunlight or inclement weather.
- Charge the device at least every 3 months to maintain battery performance during the offseason.

Document No. G20247010C01

Email：support@wybotpool.com Facebook: @WybotPool Website: www.wybotpool.com